


Scale House Operator – Incoming

The scale house operator weighing allows the operator to trigger the weighing process through Waybiller. While the truck is on the scale, the operator opens the e-waybill and presses the application's weighing button. This eliminates manual data entry, speeds up the process, and ensures that only authorized trucks are processed.



Cheatsheet

¹ Creates a waybill: The driver logs into the Waybiller app on their mobile device and creates the e-waybill directly in Waybiller by selecting the origin, destination, and assortment transported or by choosing a **transport order.***

² Driver logs in: The logistics team assigns a transport order to a vehicle as a one-time or recurring task for ongoing deliveries. If given the right, it is also possible for the driver to create the transport order. The driver selects the assigned transport order, marks the start of the journey, and generates an e-waybill for weighing.

³ The weighing button: The scale operator presses the weighing button on the waybill. A weighing request is made, and stabilized tare/gross weight is displayed to the scale operator on the transport order. Boom will rise, and the traffic light will go green.

⁴ Gross weighing: Weighing the loaded truck to record its total weight. Depending on the sector, the receiver/ laboratory technician also analyses the load at this point.

⁵ Tare weighing: Weighing the truck after it is unloaded to calculate the net weight of the material.

⁶ E-waybill: After weighing, an e-waybill is automatically generated with tare, gross, and net weights and sent as a PDF to selected email addresses. The e-waybill is available to all involved parties in real time and can be exported to Excel for further processing. *The e-waybill is directly imported into the accounting system if integrated with accounting.*